

# IPE INSTRUCTIONS



Step 1) Clean IPE with Super Cleaner (SKU50800). Rinse and let dry. Can be used in Hy pressure washer. Do not exceed 600-800 psi

Step 2) Apply one liberal coat of Fluoroblend (SKU66070), Will act as primer and sealer. Allow 4 to 6 hours ,must be dry before applying Teak Shield. (SKU40081)

Step 3) Apply Teak Shield (SKU40081) when Fluoroblend is dry. Add Crosslinker (catalyst) (SKU70014) Instant induction. Allow 6-8 hours before applying second coat of Teak Shield SKU40081.

Step 4) Apply 2<sup>nd</sup> coat of Teak Shield SKU40081 . Allow first coat to dry hard enough to walk on (6-8 hours) subject to temperature and humidity, before applying this second coat. Product has an 18 hour window for application of the 2<sup>nd</sup> coat or wait 7 days for full cure.

Once product is fully cured it can be cleaned with any normal cleaner. The longer it dries, the harder it becomes. 7 days is considered fully cured. Time to put furniture on it. You ca normally walk on it in 24 hours.

Super Shield can be recoated at any time without re-sanding. Just clean it first. You should always test wood with a moisture meter prior to application.

**Warning: Do not clean with any type of Bleach, especially Chlorine. This will void warranty**

Shield Products- Tel-904-880 6060 Fax 904-645-6155  
[www.shieldproducts.com](http://www.shieldproducts.com) [e-mail-shieldproducts@comcast.net](mailto:e-mail-shieldproducts@comcast.net)

# IPE INSTRUCTIONS

**"WHEN YOU WANT THE VERY BEST"**